

THINK TECHSMART® FIRST

Park Assist Sensors

TechSmart® parking sensors are matched 100% to the OE body style. Each parking sensor is guaranteed to fit and perform just like the original. Each TechSmart® parking sensor connector is molded into the body just like the OE. Beware of universal style sensors that use a pigtail connector in place of the OE style molded design.



TechSmart® T36004



Competitor

High Failure Rate Original Part. THINK TECHSMART FIRST for High-Quality, Park Assist Sensors.



T36001

- Ford Edge 2011-07, Ford Five Hundred 2007-05, Ford Fusion 2009-08, Ford Taurus 2009-08, Ford Light Truck Taurus X 2008, Lincoln MKX 2010-07, Lincoln MKZ 2009-08, Mercury Milan 2009-08, Mercury Montego 2007-05, Mercury Sable 2009-08



T36006

- Ford E Series Fullsize Van 2009-07, Ford Escape 2009-08, 2006-01, Ford Expedition 2006-03, Ford Explorer/Sport/Sport Trac 2009-02, Ford F Series Fullsize Pickup 2011-10, 2009-01, Ford Freestar 2007-04, Ford Windstar 2003-01, Lincoln Blackwood 2002, Lincoln Mark LT 2008-06, Lincoln Navigator 2002-01, Mercury Mariner 2009-08, 2006-05, Mercury Monterey 2007-04, Mercury Mountaineer 2006-02



T36002

- Ford Escape 2007, Mercury Mariner 2007



T36003

- Ford Freestyle 2007-05



T36007

- Ford Expedition 2003, Lincoln LS 2006-03, Lincoln Navigator 2006-03, Lincoln Town Car 2005-03



T36004

- Ford Expedition 2003, Lincoln LS 2006-03, Lincoln Navigator 2006-03, Lincoln Town Car 2005-03



T36017

- Mercedes-Benz 2003-92

For more parking sensors, please visit www.techsmartparts.com



ARE YOU TECHSMART®?

